

2015 COROLLA
Quick Reference Guide

2015 Corolla

This *Quick Reference Guide* is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The *Quick Reference Guide* is not intended as a substitute for the *Owner's Manual* located in your vehicle's glove box. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor Sales, U.S.A., Inc. wish you many years of satisfied driving in your new Corolla.

A word about safe vehicle operations

This *Quick Reference Guide* is not a full description of Corolla operations. Every Corolla owner should review the *Owner's Manual* that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the *Owner's Manual*. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this *Quick Reference Guide* is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Engine maintenance	9
Fuel tank door release and cap	8
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Keyless entry¹	6
Smart Key system¹	7

FEATURES/OPERATIONS

Air Conditioning/Heating	16
Audio	18
Auto lock/unlock²	11
Automatic Transmission	10
Auxiliary storage	20
Bluetooth® Device Pairing Section	27-36
Clock	14
Continuously Variable Transmission	10
Cruise control	17
Cup holders-Adjust size	20
Drive monitor display/Multi-Information Display	15
iPod®/USB/AUX port	14
Light control-Instrument panel	20
Lights & turn signals	13
Manual Transmission	10
Moonroof	15
Parking brake	11
Power outlet	14
Seat adjustments-Front	11
Seats-folding rear	12
Seat heaters	17
Seats-Head restraints	12
Steering wheel switches and telephone controls (Bluetooth®)	19
Tilt and telescopic steering wheel	15
Windows-Power	12
Windshield wipers & washers	12

SAFETY AND EMERGENCY FEATURES


Doors-Child safety locks	21
Floor mat installation	25
Seat belts	21
Seat belts-Shoulder belt adjustment	21
Spare tire & tools	23
Star Safety System™	24-25
Tire Pressure Monitoring (warning) System	22
Trunk-Internal release	22

¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the *Owner's Manual* for instructions and more information.

OVERVIEW

Instrument panel




- ❶ Steering wheel audio controls
- ❷ Paddle shift switches*
- ❸ Telephone controls
- ❹ Voice command button*
- ❺ “DISP” switch
- ❻ Cruise control*
- ❼ Power outside rearview mirror controls
- ❽ Instrument panel light control dial
- ❾ Headlight, turn signal and front fog light* controls
- ❿ Meters
- ⓫ Drive monitor display* or Multi-Information Display*
- ⓬ Wiper and washer controls
- ⓭ Emergency flasher button
- ⓮ Clock
- ⓯ Audio system*, multimedia system* or navigation system*/Rearview monitor*
- ⓰ Air Conditioning controls
- ⓱ Shift lever
- ⓲ Parking brake
- ⓳ Engine switch*
- ⓴ Key ignition*
- ⓵ Tilt and telescopic steering control
- ⓶ Hood lock release lever
- ⓷ Tire Pressure Monitoring (warning) System reset

* If equipped

NOTE: For vehicles equipped with Entune® App Suite, please consult the “Entune® Premium Audio with Navigation and App Suite Quick Reference Guide” or www.toyota.com/entune.

Instrument cluster



Indicator symbols

For details, refer to “Warning lights and indicators,” Section 2, *2015 Owner’s Manual*.


- BRAKE Brake system warning¹
- Seat belt reminder (alarm will sound if speed is over 12mph)
- Charging system warning¹
- “AIRBAG ON/OFF” indicator

- Electric power steering warning¹
- Malfunction/Check Engine indicator¹
- Low fuel level warning
- Open door warning
- SRS airbag warning¹
- Low Tire Pressure Warning¹
- Headlight high beam indicator
- Turn signal indicator
- Front fog light indicator
- Slip indicator¹
- Cruise control indicator
- Cruise control SET indicator
- Anti-lock Brake System warning¹
- Vehicle Stability Control OFF indicator¹
- Low engine oil pressure warning¹
- Maintenance/Service required indicator¹
- Traction control OFF indicator¹
- High engine coolant temperature warning¹
- Master warning¹
- Headlight indicator
- Sport mode indicator
- ECO driving indicator light¹
- “ECO MODE” indicator
- Smart key system indicator
- Security indicator


¹ If indicator does not turn off within a few seconds of starting engine, there may be a malfunction. Have vehicle inspected by your Toyota dealer.

Keyless entry (if equipped)

Locking operation




Unlocking operation



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

Trunk lid




Panic button




Smart Key system (if equipped)

Start function

Vehicles without a Multi-Information Display



Vehicles with a Multi-Information Display



NOTE: Carry the electronic key to enable start function. Gear shift lever must be in Park and brake pedal depressed.


Power (without starting engine)

Without depressing the brake pedal, pressing the engine switch will change the operation mode in succession from:

- ACC** Accessories such as the radio will operate.
- ↓
- ON** Power ON; the engine not running.
- ↓
- OFF** All systems OFF.

Locking operation

Front door lock



Carry remote to lock


Unlocking operation

Front door unlock*



Carry remote to unlock

Trunk open




Carry remote to open


* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping front passenger door handle will unlock all doors.

NOTE: Doors may also be locked/unlocked using remote.


Fuel tank door release and cap



Hood release



Engine maintenance




- ❶ Windshield washer fluid tank
- ❷ Engine oil filler cap
- ❸ Engine oil level dipstick
- ❹ Engine coolant reservoir

NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty Maintenance Guide.”

FEATURES/OPERATIONS


Automatic Transmission (if equipped)




* The engine switch must be "ON" and the brake pedal depressed to shift from Park.

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Manual Transmission (if equipped)



Continuously Variable Transmission (if equipped)



¹ The engine switch must be "ON" and the brake pedal depressed to shift from Park.

Changing gear steps in the M position

Shift the shift lever to "M" position from "D" position.

- +: Upshifting
- : Downshifting

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Auto lock/unlock

Automatic door locks can be programmed to operate in two different modes, or turned OFF.

- Doors lock when shifting from Park.
- Doors lock when the vehicle speed is approximately 12 mph or higher.
- Doors unlock when shifting into Park.

Vehicles without Smart Key system


-Doors unlock when the engine switch is set from "ON" to "ACC" or "LOCK" and driver's door is opened.

Vehicles with Smart Key system

-Doors unlock when the engine switch is set to OFF and driver's door is opened.


Refer to the *Owner's Manual* for more details.

Seat adjustments-Front




- 1 Seat position (forward/backward)
- 2 Height crank (driver side only)
- 3 Seatback angle
- 4 Seat position, cushion angle and height
- 5 Seatback angle


Parking brake




Seats-folding rear



Seats-Head restraints




Windows-Power




Automatic operation (driver's window only) Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch Deactivates all passenger windows. Driver's window remains operable.


Windshield wipers & washers




Lights & turn signals




Front fog lights (if equipped)



Turn signals




Power outlet



The engine switch must be in the “ACC” or “ON” position for use.

iPod®/USB/AUX port




iPod®/USB port

By connecting a USB-compatible portable audio device or USB memory to the USB port, you can listen to music from the portable audio device or USB memory through the vehicle’s speaker system.

AUX port

By inserting a mini plug into the AUX port, you can listen to music from a portable audio device through the vehicle’s speaker system while in AUX mode.


Clock



Moonroof (if equipped)


Sliding operation

Recommended open position to minimize wind noise.




Push once to open partway; again to open completely.

Tilting operation




Tilt and telescopic steering wheel




NOTE: Do not attempt to adjust while the vehicle is in motion.

**Drive monitor display/
Multi-Information Display**

Drive monitor display



Multi-Information Display




- ❶ Engine coolant temperature gauge
- ❷ ECO Driving Indicator Zone Display*
- ❸ Outside temperature display
- ❹ Shift position and gear position indicator*
- ❺ Trip information
- ❻ Driving monitor
- ❼ Warning messages

* Except vehicles with Manual Transmission.


Air Conditioning/Heating

Automatic Air Conditioning




- ❶ Automatic climate control ON
Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically.
 - ❷ Temperature selector
 - ❸ Air Conditioning ON/OFF
 - ❹ Recirculate cabin air (fresh air when OFF)
 - ❺ Fan speed
 - ❻ Airflow vent
In “” or “” mode, use fresh air (“” indicator OFF) to reduce window fogging.
 - ❼ Outside rearview mirror*/Rear defogger
 - ❽ Windshield airflow/defogger
 - ❾ Climate control OFF
- * If equipped

Manual Air Conditioning




- ❶ Airflow vent
In “” or “” mode, use fresh air (“” indicator OFF) to reduce window fogging.
 - ❷ Fan speed
 - ❸ Temperature selector
For quick cooling, turn to MAX A/C position and select recirculated air mode (“” indicator ON).
 - ❹ Air Conditioning ON/OFF
 - ❺ Outside rearview mirror defoggers*/Rear window defogger
 - ❻ Recirculate cabin air (fresh air when OFF)
- * If equipped

Seat heaters (if equipped)




Cruise control (if equipped)

Turning system ON/OFF



Functions



- ¹ The set speed may also be cancelled by depressing the brake pedal.
- ² The set speed may be resumed once vehicle speed exceeds 25 mph.

Audio (if equipped)

Type 1

Type 2 - Entune Audio Plus (additional functions)

Type 3 - Entune Premium Audio with Navigation and App Suite (additional functions)

¹ Refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

- 1 AUDIO Button
Access to audio functions.
- 2a APPS Button
Access to traffic and weather
- 2b APPS Button
Access to Entune® App Suite, sports, stocks, news, traffic and weather

- 3 HOME Button
Access to Home screen.
HOME SCREEN - the home screen offers a two panel and a three panel layout. Information and layout will vary depending on selected set up.

Steering wheel switches and Telephone controls (Bluetooth®)

Type A

Type B

1 "▲ ▼" Use to search within the selected audio medium (radio, CD, iPod®, etc.).

2 "MODE" Push to turn audio ON and select an audio mode. Push and hold to turn the audio OFF.


Vehicles with moonroof

Vehicles without moonroof


Bluetooth® technology allows dialing or receipt of calls without taking hands from the steering wheel or using a cable to connect the compatible telephone and the system.

Refer to Section 5 in the *Owner's Manual*, for more information about phone connections and compatibility.


Light control-Instrument panel




Cup holders-Adjust size



Auxiliary storage




Seat belts




If belt is fully extended, then retracted even slightly, it cannot be re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the *Owner's Manual*.

Seat belts-Shoulder belt adjustment




Doors-Child safety locks



Pushing down the lever will allow the door to be opened only from the outside.

Tire Pressure Monitoring (warning) System




After adjusting tire pressures, or after tires have been rotated or replaced, turn the engine switch to “ON” and press and hold the “SET” button until indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete.

Refer to the load label on the door jamb or the *Owner’s Manual* for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.


NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Trunk-Internal release




Spare tire & tools

Tool location



Removing the spare tire



- (1) Remove the luggage floor cover.
- (2) Remove the tool tray.
- (3) Loosen the center fastener that secures the spare tire.

Refer to the *Owner’s Manual* for tire changing and jack positioning procedures.

Star Safety System™

All new Toyota vehicles come standard with the Star Safety System™, which combines Vehicle Stability Control (VSC), Traction Control (TRAC), Anti-lock Braking System (ABS), Electronic Brake-force Distribution (EBD), Brake Assist (BA) and Smart Stop Technology (SST).

Vehicle Stability Control (VSC)

VSC helps prevent loss of traction during cornering by reducing engine power and applying brake force to selected wheels.

Toyota's VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces engine power and applies braking to selected wheels. This helps restore traction and vehicle control.

Traction Control (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).

Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Anti-Lock Brake System (ABS)

ABS helps prevent brakes from locking up by “pulsing” brake pressure to each wheel. This limits brake lockup and helps provide directional control for the current road conditions.

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by “pulsing” each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

Electronic Brake Force Distribution (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. Abrupt stops can cause a vehicle to tilt forward, reducing the braking power of the rear wheels. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

Brake Assist (BA)

Brake Assist is designed to detect sudden or “panic” braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

Smart Stop Technology (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.


SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION

BLUETOOTH DEVICE PAIRING

To begin, Please refer to page 18 to determine which audio system your vehicle is equipped with: Type 1, 2, or 3. If your vehicle is equipped with Type 2 or 3 audio, there are specific instructions for each major type of phone (Android, Windows or iPhone) on the following pages.

Press the HOME button on the face plate on Types 2 & 3.


Bluetooth Pairing with Standard non-touch display audio unit (Type 1)*

1. Press "SETUP" button.
2. Turn the right dial and push to select "Bluetooth".
3. Push to select "Bluetooth Pairing".
4. Go to your phone and access Bluetooth settings.
5. On your phone, touch the device to be paired.

Bluetooth Pairing for Android phone and Entune touch screen system (Types 2 & 3)


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection.*

Initiate Bluetooth on your Android




STEP 1

From your APPS SCREEN, select SETTINGS



STEP 2

Select CONNECTIONS and select BLUETOOTH



STEP 3

Ensure BLUETOOTH is ON



STEP 4

Select YOUR PHONE DEVICE to make it discoverable.

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

* Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

Initiate Bluetooth on your Entune Multimedia Head Unit

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select SETUP BUTTON on the Home Screen.




STEP 7

Select BLUETOOTH



STEP 8

Select ADD, to add your phone device



STEP 9

Back on your smartphone, you can now select your TOYOTA VEHICLE in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.


Initiate Bluetooth on your Entune Multimedia Head Unit (continued)



STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts

It is recommended to check the "Don't ask again" box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google, Inc. All rights reserved. Google is not a participant in or sponsor of this promotion.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.
5. Bluetooth Pairing Guide for select 2014 models.

Bluetooth Pairing for iPhone and Entune touch screen system (Types 2 & 3)


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth®. This pairing process is quick and easy: all iPhone® mobile digital devices have Bluetooth® integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection. Bluetooth Pairing Guide for select 2014 models.

Initiate Bluetooth on your iPhone



STEP 1

From the HOME SCREEN, select SETTINGS



STEP 2

Select BLUETOOTH



STEP 3

Ensure BLUETOOTH is ON



STEP 4

Your iPhone will seek out Bluetooth devices while remaining discoverable



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

CONTINUE ON THE NEXT PAGE...

BLUETOOTH DEVICE PAIRING


Initiate Bluetooth on your Entune Multimedia Head Unit (iPhone pairing contined)

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

Select **SETUP** BUTTON on the Home Screen.



STEP 7

Select **BLUETOOTH**



STEP 8

Select **ADD**, to add your phone device



STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.




STEP 10

Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.



STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

- This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.
1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
 2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
 3. Android is a trademark of Google, Inc. All rights reserved. Google is not a participant in or sponsor of this promotion.
 4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.
 5. Bluetooth Pairing Guide for select 2014 models.

Bluetooth Pairing for Windows phone and Entune touch screen system (Types 2 & 3)

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth®. This pairing process is quick and easy: all Windows Phone® mobile digital devices have Bluetooth® integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection. Bluetooth Pairing Guide for select 2014 models.


Initiate Bluetooth on your Windows Phone



STEP 1
From your APP LIST, select **SETTINGS**



STEP 2
Select **BLUETOOTH**



STEP 3
Ensure **BLUETOOTH** is **ON**



STEP 4
Phone will seek out Bluetooth devices while remaining discoverable



STEP 5
While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.
CONTINUE ON THE NEXT PAGE...

Initiate Bluetooth on your Entune Multimedia Head Unit


Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




STEP 6
On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



STEP 7
Select **BLUETOOTH**




STEP 8
Select **ADD**, to add your phone device



STEP 9
Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.
You may need to enter the provided Bluetooth PIN on your phone.



STEP 10
Your smartphone is now paired with Entune.




STEP 11
Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth on your Entune Multimedia Head Unit (continued)



STEP 12

Using your smartphone, you may need to allow Entune access to your contacts



STEP 13

A confirmation will appear that your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer Experience Center
 (800) 331-4331

- Disclosures
- This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.
1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
 2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
 3. Android is a trademark of Google, Inc. All rights reserved. Google is not a participant in or sponsor of this promotion.
 4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.
 5. Bluetooth Pairing Guide for select 2014 models.

